# **ADIBO**



# 文迪宝智能羽毛球发球机

A260(蓝牙单机版)使用说明书

ADIBO Intelligent Badminton Serving Machine

A260 (Bluetooth standalone version) instructions

# 艾迪宝体育用品(深圳)有限公司

ADIBO TECHNOLOGY CO., LIMITED

地址:深圳市龙华区龙华街道清湖社区清湖工业城辉盛达厂房2栋3层 Address: 3rd Floor, Building 2, Hui Sheng Da Industrial Park, Qinghu Community,Longhua Street, Longhua District, Shenzhen City Web: www.adibo.com



了解更多 Scan code attention

说明书最终解释权归本公司所有,在使用本产品之前请仔细阅读此说明书。 The final interpretation of the manual belongs to our company. Please read it carefully before using this product.

# I .Smart Badminton Serving Machine A260 Product Diagram






## **II** .Packing List

Item	Quantity
Tripod Stand for Serving Machine	1
Serving Machine Head (with Indicator Light)	1
Shuttlecock Bucket	1
Bucket Post	1
2.5 mm Allen Wrench	1
Certificate of Conformity	1
Power Adapter	1
Signal Antenna	1

#### **III** .Installation Instructions

### **Smart Badminton Serving Machine**




Bucket Lid x1


Lower Shuttlecock Bucket Lid x1

### **Shuttlecock Bucket Installation Steps**

# Install the shuttlecock bucket support pole. Take out the hexagonal wrench, 8 screws, and 4 support rods from the street of the

screws, and 4 support rods from the accessory bag: each support rod corresponds to one of the four holes on the lower ball bucket lid; use the hexagonal wrench to insert and tighten the screws from the bottom side of the lower ball bucket lid.






Place the shuttlecock bucket tubes into the circular recesses on the lower shuttlecock bucket lid.



#### Installation of Upper Shuttlecock Bucket Lid

After installing the upper shuttlecock bucket lid, make sure to fine-tune each shuttlecock bucket tube so that it fits securely into the recesses. Finally, use a hexagonal wrench to insert and tighten the screws from the top side of the upper shuttlecock bucket lid.




#### Installation Completed





#### **Serving Machine Installation Steps**


#### Unfold the tripod.











# IV. Download and install the operating application

1. Scan lower part or the QR Code of the machine body to download and install the ADIBO Intelligent Serving Machine Operating Application.








ios app download

# **V** .Brief Instructions for Operation:

1. Place the assembled smart serving machine in the center of the court (as shown in the figure below).






- 2. Power on the intelligent serving machine, wait for the power indicator on the head of the serving machine to light up, and after the self-inspection of the left and right steering of the serving machine, when only the power indicator is on.
- 3. Enter the ADIBO intelligent serving machine operation application, click the standalone version, select the badminton serving machine, select the operation serving machine code at the top of the confirmation, and click the confirmation. After the machine is turned on, the power, network and working indicator lights on the head of the serving machine are on at the same time.




4. Enter the "Operation" column in the ADIBO Smart Serving Machine application.



5. Preset training: Select the corresponding training ball path according to your own training needs, and click the start serving machine to start serving.



6. Customization: The graphical interface shows the half of the badminton court of the opponent of the service machine. Press and hold the required landing point for 2 seconds on the schematic diagram to select. After selection, click below to start.



7. Customized parameter adjustment diagram is shown as follows:





#### 8. Explanation of parameter adjustment button:



9. Archive: After selecting the training ball path, click Save to save the current ball path as a training archive. In the future, you can directly click Start in "My Archive" for quick training.



# **VI**.Troubleshooting

Malfunction	Cause of failure	Exclusion method
The serving machine is not powered.	Whether the socket is electrified     Poor contact between power cord plug and socket     Applicable voltage of machine power supply	<ol> <li>Take other electrical equipment to check whether there is electricity.</li> <li>Check the power plug and socket</li> <li>Check whether the socket voltage is within the applicable range.</li> </ol>
The ball machine does not play the ball.	① The machine is not connected to Bluetooth ② Startup is not successful	① Check whether the network indicator behind the head of the serving machine is on. If it is not on, please wait for one minute after power off and restart. If it is not solved, please contact the official after-sales service. ② Check whether the working indicator behind the head of the serving machine is on. If not, check the mobile phone.
The ball machine is powered on and the network is not connected.	① The Bluetooth function of the mobile phone is not turned on ② Signal antenna is not installed	① Turn on the Bluetooth of the mobile phone and find the machine ② Install the signal antenna at the back of the server head.
The mobile phone cannot control the machine.	① Interruption of machine signal	① Power off and restart the machine
The buzzer goes on and on.	① There is foreign matter in the transmission chain card of the serving machine.	① Check and remove the foreign matters stuck in the transmission chain when the power is off.

## **VII .Frequently Asked Questions**

- 1. Do not touch the rotating part when the serving machine is working;
- 2. When the serving machine pauses and adjusts its functions, do not contact the ball outlet at a close distance, and remind the people in the front court to pay attention to safety before starting the machine;
- 3. Minors must operate and use under the guidance of adults;
- 4. Avoid rain and snow during outdoor use;
- 5. When the machine is lifted or lowered, the non-operator shall not approach the lower part of the machine to avoid unnecessary injury;
- 6. When the serving machine is working, in case of abnormal phenomena such as peculiar smell or smoke, please immediately press the emergency switch and unplug the power plug:
- 7. Please turn off the machine and unplug the power supply after use;



# **Warranty Card**

Dear Customer,

#### Greetings!

Thank you for purchasing ADIBO brand products. Please be sure to carefully read the product manual before use to ensure proper operation. In case of malfunction, please first refer to the [Troubleshooting] section in the product manual. If the issue cannot be resolved through troubleshooting, please contact our after-sales department as soon as possible for quality service.

You are welcome to call our service hotline at 4000-009-773 for inquiries.

#### Warranty Terms:

- 1. Warranty Period: The warranty period for the ADIBO Smart Serving Machine Model A260 is one year, and three months for consumable parts such as the serving wheel and shuttlecock bucket.
- 2. Covered Repairs: During the warranty period, any malfunctions that occur under normal usage conditions as per the user manual (as determined by our official staff) will be repaired free of charge.
- 3. Exclusions:During the warranty period, repairs will be charged in the following situations:
- •Inability to provide this warranty certificate and valid purchase proof.
- ·Malfunctions and damages caused by incorrect usage or improper self-repair.
- •Malfunctions or damages caused by transport, moving, or dropping after purchase.
- Malfunctions and damages caused by unavoidable external factors.
- Damages caused by water ingress or other solutions due to improper use.
- Damages caused by using unspecified power sources or voltages.
- 4. Limitation of Liability: This warranty is the only express or implied warranty provided (including implied warranties of merchantability, suitability for a particular purpose, and fitness for application), and regardless of contract, negligence, or otherwise, our company is not responsible for any special, incidental, or consequential damages.
- 5. Return Shipping:Please package the product properly for repair and transportation. Our company is not liable for any damage during transit.

Best regards,

ADIBO Customer Service Team

Product Warranty Card			
Product Name			
Serving Machine Model	Date of Purchase		
Customer Name	Contact Phone Number		
Customer Address			

# 一、智能羽毛球发球机A260产品示意图






## 二、装箱清单

名 称	数量	单位
发球机三角架	1	个
发球机机头(带指示灯)	1	个
羽毛球球桶	1	个
球桶柱	1	个
2.5内六角扳手	1	把
电源适配器	1	个
合格证	1	张
说明书及保修卡	1	本
信号天线	1	根

## 三、安装说明

#### 1.智能羽毛球发球机配件清单




#### 2.球桶安装步骤

# 安装球桶支撑杆 取出配件包内的六角扳手。8个螺丝、4根支撑杆; 每个支撑杆对应在下球桶盖上方的4个孔洞内; 使用六角扳手将螺丝从下球桶盖的下方放入拧紧。

#### 安装上球桶盖

安装好上球桶盖后, 注意微调各球桶管使其卡入圆孔凹槽内, 最后使用六角扳手将螺丝从上球桶盖的上方放入拧紧。







安装完成

#### 3.发球机安装步骤


#### 展开三脚架











## 四、下载安装操作应用程序

1、扫描下方或机身二维码下载并安装艾迪宝智能发球机操作应用程序。






安卓应用下载

苹果应用下载

### 五、操作程序简要说明

1、将组装好的智能发球机放置球场中间(如下图所示)。





- 2、将智能发球机通电,待发球机机头上的电源指示灯亮起,发球机左右转向自检后,在只有电源指示灯亮的情况下。
- 3、进入艾迪宝智能发球机操作应用程序,点击单机版,选择羽毛球发球机,在确认上方选操作发球机编码,点击确认,机器开启后发球机机头上:电源、网络、工作指标灯同时长亮。



4、艾迪宝智能发球机应用程序中进入"操作"栏目。



5、预设训练:根据自已训练需求选择相应训练球路,点击开始发球机发始发球。



6、自定义: 图形界面所示为发球机对方的半片羽毛球场地, 在所需落点示意图上 长按2秒选择, 选择完毕后, 点击下方开始即可。



#### 7、自定义参数调整图解如下所示:





#### 8、参数调节按钮解释:



9、存档:在自定义选择好训练球路后,点击保存,可将当前球路保存为训练存档,以后训练直接在"我的存档"中点击开始即可快速训练。



### 六、故障排除

故障	故障原因	排除方法
发球机 不通电	①插座是否有电 ②电源线插头与插座接触不良 ③ 机器电源适用电压	①拿其它用电设备排除是否有电 ②检查电源插头、插座 ③ 检查插座电压是否在适用范围内
发球机 不出球	①机器没有连接蓝牙 ②开机没有成功	①检查发球机机头后面网络指示灯是 否亮起如没有亮起,请断电重启后等待 一分钟,如还未解决请联系官方售后。 ②检查发球机机头后面工作指示灯是 否亮起,如没有亮起,查看手机。
发球机 通电网络 连不上	①手机蓝牙功能没有打开 ②信号天线未安装	①手机蓝牙开启找到该机器 ② 将信号天线安装在发球机头后部
手机控制 不到机器	①机器信号中断	①断电重启机器
蜂鸣器长鸣不止	①发球机传送链条卡有异物	①断电的状态下检查并清除传送链条 卡着的异物

# 七、常见问题

- 1、发球机在工作时请勿触摸转动部分;
- 2、发球机暂停、调节功能时切勿与出球口近距离正面接触,并提醒前方球场内人员注意安全后方可开机工作;
- 3、未成年人必须在成年人的指导下操作使用;
- 4、室外使用时,须避免雨、雪天气;
- 5、机器升、降时,非操作人员切勿靠近机器下方,以免造成不必要伤害;
- 6、发球机工作时,如出现异味或冒烟等非正常现象,请立即按下紧急开关及拔掉 电源插头;

7、使用结束请关机并拔掉电源;



# \*

# 保修卡

#### 尊敬的用户:

#### 您好!

感谢您购买(ADIBO)艾迪宝品牌系列产品,请您在使用前务必认真阅读产品说明书,以备准确的使用。如发生故障时,请事先对照产品说明书[故障排查]检查,在[故障排查]中不能排除故障的情况下,请尽早联系我公司售后部门,我公司将为您提供优质的售后服务。

欢迎您拨打我公司服务热线:4000-009-773进行咨询。

#### 保修条例:

- 1. 艾迪宝智能发球机整机A260保修期为壹年,发球轮、羽毛球桶、为易耗件保修期为三个月。
- 2. 在保修期间,按照使用说明书进行正常使用的状况下产生的故障(由本公司正式工作人员判定),予以免费修理。
  - 3. 在保修期间, 如发生以下情况之一, 必须作为收费修理:
  - 不能够提供本保证书及有效购货凭证。
  - 错误使用以及自行不当的修理所造成的故障及损坏。
  - 买入后的运送、搬动、跌落造成的故障或损坏。
  - 其它不可避免的外来因素造成故障及损坏。
  - 使用不当导致设备进水或其它溶液造成的损坏。
  - 使用指定以外的电源,电压所造成的损坏。
- 4.仅作以上保证,不作其它任何明示或默示性的保证(其中包括适销性、对某种特定的与应用的合理性与适应等的默示保证),不论在合同中、民事过失上、还是其它方面,本公司不对任何特殊的、偶然的或间接的损害负责。
  - 5. 送修产品请妥善包装运送,运送过程中如有损毁,本公司恕不负责。

产品保修卡		
产品名称		
产发球机编号	购买日期	
客户名称	联系电话	
客户地址		