



ADIBO

艾迪宝智能羽毛球发球机

A280 (蓝牙单机版) 使用说明书

ADIBO Intelligent Badminton Serving Machine

A280 Premium Edition User Manual



艾迪宝体育用品(深圳)有限公司

ADIBO TECHNOLOGY CO., LIMITED

地址: 深圳市龙华区龙华街道清湖社区清翠路29号辉盛达厂房2栋五层505

Address: 505, 5/F, Building 2, Huishengda Industrial Park, Qingcui Road,
Longhua District, Shenzhen, Guangdong, China

Web: www.adibo.com

说明书最终解释权归本公司所有, 在使用本产品之前请仔细阅读此说明书。

The final interpretation of the manual belongs to our company.

Please read it carefully before using this product.

Warranty Card

Dear Customer,

Greetings!

Thank you for purchasing ADIBO brand products. Please be sure to carefully read the product manual before use to ensure proper operation. In case of malfunction, please first refer to the [Troubleshooting] section in the product manual. If the issue cannot be resolved through troubleshooting, please contact our after-sales department as soon as possible for quality service.

You are welcome to call our service hotline at 4000-009-773 for inquiries.

Warranty Terms:

- 1. Warranty Period: The warranty period for the ADIBO Smart Serving Machine Model A260 is one year, and three months for consumable parts such as the serving wheel and shuttlecock bucket.
- 2. Covered Repairs: During the warranty period, any malfunctions that occur under normal usage conditions as per the user manual (as determined by our official staff) will be repaired free of charge.
- 3. Exclusions: During the warranty period, repairs will be charged in the following situations:
 - Inability to provide this warranty certificate and valid purchase proof.
 - Malfunctions and damages caused by incorrect usage or improper self-repair.
 - Malfunctions or damages caused by transport, moving, or dropping after purchase.
 - Malfunctions and damages caused by unavoidable external factors.
 - Damages caused by water ingress or other solutions due to improper use.
 - Damages caused by using unspecified power sources or voltages.
- 4. Limitation of Liability: This warranty is the only express or implied warranty provided (including implied warranties of merchantability, suitability for a particular purpose, and fitness for application), and regardless of contract, negligence, or otherwise, our company is not responsible for any special, incidental, or consequential damages.
- 5. Return Shipping: Please package the product properly for repair and transportation. Our company is not liable for any damage during transit.

Best regards,
ADIBO Customer Service Team

Product Warranty Card			
Product Name			
Serving Machine Model		Date of Purchase	
Customer Name		Contact Phone Number	
Customer Address			



I. Product Schematic Diagram of A280




II . Packing List


Name	Quantity
Triangular Support Frame	1
Ball Serving Head (with Indicator Light)	1
Badminton Shuttlecock Container	1
Accessory Box	1
3.5mm Allen Wrench	1
Power Adapter	1
Manual & Warranty Card	1
Signal Antenna	1
Tablet PC	1

III . Installation Instructions


1.Accessory List of Ball Serving Machine




2.Installation Steps for Shuttlecock Container




3.Installation Steps for Ball Serving Machine




Install the server




Install the ball bucket column




Install the antenna




Install the power cord



Install the power adapter




Install the ball cylinder



IV. Brief Instructions for Operation Procedures

1. Place the assembled intelligent ball serving machine in the center of the badminton court (as shown in the figure below).




2. Connect the intelligent ball serving machine to the power supply. The power indicator light on the machine head will turn on. After the machine completes left-right rotation self-inspection, the left and right power indicator lights will stay on.


3. Launch the ADIBO Intelligent Badminton Ball Serving Machine App, click on "Standalone Mode," select the badminton ball serving machine, confirm the above operations and connection indicators, then click "Confirm." After the lights turn on, activate the machine head—the power, network, and work indicator lights will stay on simultaneously.




4. Enter the "Operations" section in the ADIBO Intelligent Badminton Ball Serving Machine App.




5. Preset Training: Select the corresponding training course based on your training needs, then click "Start" for the ball serving machine to begin serving.




6. Custom Mode: The graphical interface shows the opponent's half-court badminton court. Long-press to select landing positions on the 2D diagram, then click "Start" below to begin.



7. The diagram for custom parameter adjustment is as follows:



8. Save: After selecting the training course in custom mode, click "Save" to store the current course as a training archive. For future training, simply click "Start" in "My Archives" for quick access.



V. Troubleshooting

Malfunction	Causes	Solutions
The ball serving machine does not power on.	<ol style="list-style-type: none"> ① The power outlet has no electricity. ② The power adapter is damaged or has poor contact. ③ The power switch is not turned on. 	<ol style="list-style-type: none"> ① Check other powered outlets for electricity, or inspect the main power supply. ② Check if the light at the rear mesh cover of the machine casing is on. If not, contact after-sales service. ③ Verify that the power switch is in the "on" position.
The ball serving machine does not serve.	<ol style="list-style-type: none"> ① There are no badminton shuttlecocks in the container. ② The serving wheel is blocked by foreign objects. ③ The machine has a malfunction. 	<ol style="list-style-type: none"> ① Check if there are badminton shuttlecocks in the container. ② Check if the light at the center of the machine body is on. If not, contact after-sales service. ③ Inspect the ball feeding strip for foreign objects. If clear, the strip may be faulty.
The serving interval of the ball serving machine is inaccurate.	<ol style="list-style-type: none"> ① The manual serving count setting is abnormal. ② The signal antenna is not installed. 	<ol style="list-style-type: none"> ① Adjust the manual serving control buttons. ② Install the signal antenna into the rear antenna port of the serving machine and reset the antenna.
The hand control rod cannot be cranked.	<ol style="list-style-type: none"> ① The machine's signal is interrupted. 	<ol style="list-style-type: none"> ① Reconnect to the machine.
The shuttlecock container cannot be lifted.	<ol style="list-style-type: none"> ① There are foreign objects in the ball feeding strip inside the serving machine. 	<ol style="list-style-type: none"> ① Adjust the ball feeding strip in a new machine or remove foreign objects from the strip.

VI. General Warnings

1. Do not touch rotating parts while the machine is in operation.
2. When pausing or adjusting the machine, do not stand close to the ball outlet. Alert personnel on the court to safety before resuming operation.
3. Minors must use the machine under adult supervision.
4. Do not place flammable or explosive items near the machine.
5. Do not stand under the machine when raising or lowering it to avoid injury.
6. In case of abnormal noise, jamming, or other malfunctions, press the emergency stop button and unplug the machine immediately.
7. Power off and unplug the machine after use.