ADIBO



T500(蓝牙单机版)说明书

ADIBO Intelligent Tennis Ball Machine

T500 (Bluetooth standalone version) instructions



艾迪宝体育用品(深圳)有限公司

ADIBO TECHNOLOGY CO., LIMITED

地址:深圳市龙华区龙华街道清湖社区清湖工业城辉盛达厂房2栋3层 Address: 3rd Floor, Building 2, Hui Sheng Da Industrial Park, Qinghu Community,Longhua Street, Longhua District, Shenzhen City Web: www.adibo.com



了解更多 Learn More

说明书最终解释权归本公司所有,在使用本产品之前请仔细阅读此说明书。 The final interpretation of the manual belongs to our company. Please read it carefully before using this product.

I. Schematic Diagram of Intelligent Tennis Serving Machine T500



II. Packing List

Name	Quantity
T500 tennis serving machine	1
Install the ball frame	1
Power adapter	1
Certificate of conformity	1
Manual and warranty card	1

III. Installation Instructions

Unpacking and inspection:

Open the package, check all parts according to the packing list to ensure that there is no damage, and take out the tennis serving machine and its supporting ball frame.

Install the ball mounting frame:

Align the small opening end of the mounting frame with and against the top of the tennis serving machine. Make sure that the mounting frame is firmly mounted on the serving machine so that the ball can be fed smoothly.

Set the ball paddle:

Locate the " \prod " shaped paddle on top of the tennis serving machine. Lift it toward the middle into place.

Position the serving machine and start:

Place the tennis serving machine where you want to use it, making sure the equipment is secure and there is enough space around it to operate. Press the power switch to power on the serving machine

IV. Download and install the operating application

 $1. \, Scan\, QR\, Code\, below\, or\, on\, the\, machine\, body\, to\, download\, and\, install the\, Aidibao\, Smart\, Serving\, Machine\, Operation\, Application$



Android Download




IOS Download



V. Brief description of operating procedures


1. Place the assembled smart serving machine at a suitable position on the court (refer to the APP to operate the position of the ball path)



- 2. The intelligent tennis serving machine is powered on. When the power indicator on the serving machine is on, the serving wheel will turn left and right for power-on self-test.
- 3. Enter the ADIBO smart serving machine application, click the stand-alone version, select the smart tennis serving machine, select the serving machine code above the confirmation, and click the confirmation. After the machine is turned on, the power, network and working indicator lights of the serving machine will be on at the same time.




4. Enter the "Operation" column in the ADIBO Smart Serving Machine application.




5. Preset training: There are various tennis training paths, such as fixed-point training, combination training, random training, star challenge, senior high school entrance examination training, etc. Select the corresponding training path according to your own training needs, and click Start.

6. Customization: The graphical interface shows the tennis court opposite to the intelligent tennis serving machine. Select the machine and place it on the baseline or midline. Press and hold for 2 seconds on the schematic diagram of the required landing point to select. After selection, click below to start.



7. The adjustment diagram of custom ball path parameters is shown below.






8. Explanation of parameter adjustment button:



9. My Ball Path: After selecting the training ball path, click Save to save the current ball path as a training archive. In the future, you can directly click Start in "Archives" to train quickly.



VI. Troubleshooting

Breakdown	Cause of failure	Exclusion method	
The serving machine is not powered.	① Check whether the battery is charged. ② Poor contact between power line interface and battery	① Take other electrical equipment to check whether there is electricity. ② Check the power line and interface	
The ball machine does not play the ball.	① The machine is not connected to Bluetooth ② The wheel is stuck by a ball	①Check whether the network indicator behind the head of the serving machine is on. If it is not on, please wait for one minute after power off and restart. If it is not solved, please contact the official after-sales service. ②Check whether the working indicator behind the head of the serving machine is on. If not, check the order status of the mobile phone. ③Power off and check whether the ball is stuck on the service wheel.	
The ball machine is powered on and the network is not connected.	① The Bluetooth function of the mobile phone is not turned on	① Turn on the Bluetooth of the mobile phone and find the machine	
The mobile phonecannot control the machine.	① Interruption of machine signal	① Power off and restart the machine	
The ball won't go down.	① The ball poking device is not pulled up ② The lower ball mouth is blocked	① Pull the ball up. ② Check whether the lower ball mouth is stuck.	

VII. Frequently Asked Questions

- 1. Do not touch the rotating part when the serving machine is working;
- 2. When the serving machine pauses and adjusts its functions, do not contact the ball outlet at a close distance, and remind the people in the front court to pay attention to safety before starting the machine;
- 3. Minors must operate and use under the guidance of adults;
- 4. Avoid rain and snow during outdoor use:
- 5. When the serving machine is working, in case of abnormal phenomena such as peculiar smell or smoke, please immediately press the emergency switch and turn off the power source;
- 6. After use, finish the training in the mobile phone APP-training and then turn off the power.





Warranty Card

Dear Customer,

Greetings!

Thank you for purchasing ADIBO brand products. Please be sure to carefully read the product manual before use to ensure proper operation. In case of malfunction, please first refer to the [Troubleshooting] section in the product manual. If the issue cannot be resolved through troubleshooting, please contact our after-sales department as soon as possible for quality service.

You are welcome to call our service hotline at 4000-009-773 for inquiries.

Warranty Terms:

- 1. Warranty Period: The warranty period for the ADIBO Smart Serving Machine Model T500 is one year, and three months for consumable parts such as the serving wheel and shuttlecock bucket.
- 2. Covered Repairs: During the warranty period, any malfunctions that occur under normal usage conditions as per the user manual (as determined by our official staff) will be repaired free of charge.
- 3. Exclusions: During the warranty period, repairs will be charged in the following situations:
- Inability to provide this warranty certificate and valid purchase proof.
- $\bullet \ \ \text{Malfunctions and damages caused by incorrect usage or improper self-repair}.$
- Malfunctions or damages caused by transport, moving, or dropping after purchase.
- Malfunctions and damages caused by unavoidable external factors.
- $\bullet \, {\tt Damages} \, {\tt caused} \, {\tt by} \, {\tt watering ress} \, {\tt or} \, {\tt othersolutions} \, {\tt due} \, {\tt to} \, {\tt improperuse}.$
- Damages caused by using unspecified power sources or voltages.
- 4.Limitation of Liability:This warranty is the only express or implied warranty provided (including implied warranties of merchantability, suitability for a particular purpose, and fitness for application), and regardless of contract, negligence, or otherwise, our company is not responsible for any special, incidental, or consequential damages.
- 5.Return Shipping:Please package the product properly for repair and transportation. Our company is not liable for any damage during transit.

Best regards,

ADIBO Customer Service Team

Product Warranty Card			
Product Name			
Serving Machine Model	Date of Purchase		
Customer Name	Contact Phone Number		
Customer Address			

一、智能网球发球机T500产品示意图





二、装箱清单

名 称	数量	单 位
T500网球发球机	1	个
装球框	1	个
电源适配器	1	个
合格证	1	张
说明书及保修卡	1	本

三、安装说明

开箱与检查:

打开包装,根据装箱清单核对所有部件检查确保无损坏,取出网球发球机及其配套的装球框。

安装装球框:

将装球框的小口端对准并紧贴网球发球机的顶部。确保装球框稳固地安装在发球机上,以便顺利供球。

设置拨球器:

找到网球发球机顶端的"□"型拨球器。将其向中间提起至适当位置。

定位发球机并启动:

将网球发球机放置在您希望使用的位置,确保设备稳固且周围有足够的空间进行操作。按下电源开关,通电发球机

四、下载安装操作应用程序

1、扫描下方或机身二维码下载并安装艾迪宝智能发球机操作应用程序








苹果应用下载

五、操作程序简要说明

1、将组装好的智能发球机放置球场合适位置(可参考APP中,操作球路位置)



- 2、智能网球发球机通电,待发球机上的电源指示灯亮起,发球轮将左右转向,进行开机自检。
- 3、进入艾迪宝智能发球机应用程序,点击单机版,选择智能网球发球机,在确认上方选择发球机编码,点击确认,机器开启后发球机:电源、网络、工作指标灯同时长亮。



4、艾迪宝智能发球机应用程序中进入"操作"栏目。



5、预设训练: 内有定点训练、组合训练、随机训练、明星挑战、中考训练等各类网球训练球路根据自已训练需求选择相应训练球路,点击开始即可。






6、自定义:图形界面所示为智能网球发球机对面的网球场地,选择机器放在底线或者中线,在所需落点示意图上长按2秒选择,选择完毕后,点击下方开始即可。



7、自定义球路参数调整图解如下所示:



8、参数调节按钮解释:



9、我的球路:在自定义选择好训练球路后,点击保存,可将当前球路保存为训练存档,以后训练直接在"我的球路"中点击开始即可快速训练。





六、故障排除

故障	故障原因	排除方法	
发球机不通电	①检查电池是否有电 ②电源线接口与电池 接触不良	①拿其它用电设备排除是否有电 ②检查电源线路、接口	
发球机不出球	①机器没有连接蓝牙 ②有球卡住轮子	①检查发球机机头后面网络指示灯是否亮起如没有亮起,请断电重启后等待一分钟,如还未解决请联系官方售后。②检查发球机机头后面工作指示灯是否亮起,如没有亮起,查看手机订单状态。③断电检查发球轮是否有球卡住	
发球机通电网络 连不上	①手机蓝牙功能没有 打开	①手机蓝牙开启找到该机器	
手机控制不到机器	①机器信号中断	①断电重启机器	
球下不去	①拨球器未拉起 ②下球口堵住	①把拨球器拉起来 ②检查下球口是否卡住	

七、常见问题

- 1、发球机在工作时请勿触摸转动部分;
- 2、发球机暂停、调节功能时切勿与出球口近距离正面接触,并提醒前方球场内人员注意安全后方可开机工作;
- 3、未成年人必须在成年人的指导下操作使用;
- 4、室外使用时,须避免雨、雪天气;
- 5、发球机工作时,如出现异味或冒烟等非正常现象,请立即按下紧急开关及关闭电源:
- 6、使用结束后, 在手机APP-训练中结束训练 再关闭电源



保修卡

尊敬的用户:

您好!

感謝您购买(ADIBO)艾迪宝品牌系列产品,请您在使用前务必认真阅读产品说明书,以备准确的使用。如发生故障时,请事先对照产品说明书[故障排查]检查,在[故障排查]中不能排除故障的情况下,请尽早联系我公司售后部门,我公司将为您提供优质的售后服务。

欢迎您拨打我公司服务热线:4000-009-773进行咨询。

保修条例:

- 1. 艾迪宝智能发球机整机保修期为壹年,发球轮为易耗件保修期六个月。
- 2. 在保修期间,按照使用说明书进行正常使用的状况下产生的故障(由本公司正式工作人员判定),予以免费修理
 - 3. 在保修期间, 如发生以下情况之一, 必须作为收费修理:
 - •不能够提供本保证书及有效购货凭证。
 - •错误使用以及自行不当的修理所造成的故障及损坏。
 - •买入后的运送、搬动、跌落造成的故障或损坏。
 - •其它不可避免的外来因素造成故障及损坏。
 - •使用不当导致设备进水或其它溶液造成的损坏。
 - •使用指定以外的电源,电压所造成的损坏。
- 4.仅作以上保证,不作其它任何明示或默示性的保证(其中包括适销性、对某种特定的与应用的合理性与适应 等的默示保证),不论在合同中、民事过失上、还是其它方面,本公司不对任何特殊的、偶然的或间接的损害负责。
 - 5. 送修产品请妥善包装运送, 运送过程中如有损毁, 本公司恕不负责。

产品保修卡			
产品名称			
发球机编号		购买日期	
客户名称		联系电话	
客户地址			